




Watch the video here!



1

The innovative self-stabilizing mechanism of the Gyro has been designed to allow all four feet to remain firmly grounded, providing users with a stable table surface whatever the terrain.

2

With the button depressed apply gentle pressure to the center of the upper surface of the table.

3

The internal mechanism allows the feet of the Gyro base to rotate and adjust to the ground in order to remain stable.



Hold the top and rotate the legs so they are parallel for easy carrying and storage!



A

Unlock the lever underneath the top to rotate it to its vertical position until it is clipped in.

B

In the vertical position, the top needs to be moved far enough to push the stabilizing button.